

**TREK**  
**HOSC LOGIN**  
**USER GUIDE**



**May 2017**

Approved for Public Release; Distribution is Unlimited.

## TABLE OF CONTENTS

<u>PARAGRAPH</u>	<u>PAGE</u>
<b>1 Welcome.....</b>	<b>1</b>
1.1 Getting Started .....	1
<b>2 Technical Support.....</b>	<b>1</b>
<b>3 Introduction.....</b>	<b>1</b>
<b>4 Overview of the User Interface .....</b>	<b>2</b>
4.1 Main Window .....	2
4.2 Toolbar .....	3
4.3 Menus.....	3
<b>5 Quick Start Guides .....</b>	<b>3</b>
5.1 How to Start a Login Session with the HOSC .....	3
5.2 How to Change Your HOSC Login Password .....	4
5.3 How to Re-Authenticate your HOSC Login .....	4
5.4 How to Request a HOSC Login Re-Authentication Status .....	4
5.5 How to Request HOSC Common Information.....	5
<b>6 Details.....</b>	<b>5</b>
6.1 Main Window Login Area .....	5
6.2 Advanced Settings.....	6
6.3 Application Messages .....	6
6.4 Application Settings .....	8
<b>7 FAQ and Troubleshooting .....</b>	<b>8</b>

## FIGURES

<u>FIGURE</u>	<u>PAGE</u>
Figure 1 Main Window .....	2
Figure 2 Main Window General Tab.....	5
Figure 3 Advanced Settings Dialog.....	6
Figure 4 Messages Dialog .....	7
Figure 5 Configure Messages Dialog .....	7
Figure 6 Clear Messages Dialog.....	7

## 1 Welcome

The Telescience Resource Kit (TReK) is a suite of software applications and libraries that can be used to monitor and control assets in space or on the ground.

The TReK HOSC Login application provides the capability to create a login session with the Huntsville Operations Support Center (HOSC) that can be shared across TReK applications (e.g. HPEG, Command).

### 1.1 Getting Started

Start with the Introduction which provides an application overview. Next, try the Quick Start Guides for “How Tos” for common functions. For help with details, reference the Details section. See the FAQ and Troubleshooting section for helpful hints and solutions to the common “gotchas”.

## 2 Technical Support

If you are having trouble installing the TReK software or using any of the TReK software, please contact us for technical assistance:

TReK Help Desk E-Mail, Phone & Fax:

E-Mail: [trek.help@nasa.gov](mailto:trek.help@nasa.gov)  
Telephone: 256-544-3521 (8:00 a.m. - 4:00 p.m. Central Time)  
Fax: 256-544-9353

If you call the TReK Help Desk and you get a recording please leave a message and someone will return your call. E-mail is the preferred contact method for help. The e-mail message is automatically forwarded to the TReK developers and helps cut the response time. The HOSC Help Desk (256-544-5066) can provide assistance as needed and is available 24x7.


## 3 Introduction

The TReK HOSC Login application provides the capability to create a login session with the Huntsville Operations Support Center (HOSC). This login session can be shared across TReK applications (e.g. HPEG, Command).

## 4 Overview of the User Interface

### 4.1 Main Window

The main window contains several areas as shown in Figure 1. The Message Area is a dock window that you can float or dock. To float a dock window, use your left mouse button to click and hold the title area while dragging the window to another area of the screen. To dock, use the title bar to drag the dock window over the main window and drop.



**Figure 1 Main Window**

#### Toolbar

The toolbar at the top of the window provides quick access to Login and Logout.

#### Login

The Login area provides the capability to enter the information required to establish a login session with the HOSC.

#### Message Area

The Message Area displays important status and error messages. The message area can be cleared using the View menu.

## 4.2 Toolbar

The toolbar provides visual information about the state of the application and provides access to common application functions.

### Operational Status

When the Operational status is black, this indicates the login session is inactive. When the Operational status is green, this indicates the login session is active.

Use the Login button to establish a login session with the HOSC. Use the Logout button to exit the login session.

## 4.3 Menus

The HOSC Login application menus are: File, View, Options, and Help. Each of these menus is described in more detail below.

### File Menu

The File menu provides the capability to exit the application.

### View Menu

The View menu provides the capability to clear the main window message area and show and hide different areas in the main window.

### Options Menu

The Options menu provides the capability to change your HOSC password, re-authenticate your HOSC login, request a HOSC login re-authentication status, and request HOSC common information. It also provides access to the Messages dialog which can be used to display and filter application messages. Access to advanced settings is also available.

### Help Menu

The Help menu provides access to on-line help and application version information.

## 5 Quick Start Guides

This section provides “How Tos” for common functions.

### 5.1 How to Start a Login Session with the HOSC

The following steps describe the minimum necessary to start a login session with the HOSC. For additional information and details please reference section 6.1.

1. Enter a name for the login session in the HOSC Login Name field.

Note: You will use this name when referencing the login session from other TReK Applications (e.g. HPEG, Command).

2. Enter a local IP address in the Local IP Address field.

Note: If you are connecting to the HOSC, and have established a VPN Client login, you should enter the Office Mode IP Address assigned by the VPN Client. If you are connecting to a TReK training tool that is simulating the HOSC login, enter your computer's local IP address. You can use the Browse button to view and select a local IP Address.

3. Enter the HOSC information.
  - a. Enter either the HOSC Host Name or the HOSC IP Address.
  - b. Enter the HOSC Port.

Note: If you are connecting to the HOSC, enter the HOSC Host Name or IP Address and the HOSC Port. If you are connecting to a TReK training tool that is simulating the HOSC login, enter the IP Address and Port corresponding to the configuration of the training tool. For example, if you are running the training tool on the same computer as the HOSC Login application, then you would use your local IP address for the Local IP Address and the HOSC IP Address.

4. Push the Login button to activate the login sequence. You will see a series of dialogs requesting information such as Username, Password, Passcode, Role, and Mission Operational Support Mode (MOP). Enter the information requested.

Note: The Passcode is your PIN number followed by your RSA token number.

If the login session is successfully activated, the Operation status will be green.

## **5.2 How to Change Your HOSC Login Password**

The Options menu provides the capability to initiate a HOSC password change.

## **5.3 How to Re-Authenticate your HOSC Login**

The Options menu provides the capability to initiate a HOSC login re-authentication.

## **5.4 How to Request a HOSC Login Re-Authentication Status**

The Options menu provides the capability to request a HOSC login re-authentication status.

## 5.5 How to Request HOSC Common Information

The Options menu provides the capability to request HOSC Common Information. This includes various types of information such as project, mission, and database information.

## 6 Details

This section covers various application details.

### 6.1 Main Window Login Area

The Main Window Login Area is shown in Figure 2. Each field is described below.

The screenshot shows the 'TReK HOSC Login' application window. The title bar includes the application name and standard window controls. The menu bar contains 'File', 'View', 'Options', and 'Help'. Below the menu bar, there is a status bar with 'Operational' and two buttons: 'Login' and 'Logout'. The main content area is titled 'General' and contains the following fields:

- HOSC Login Name:** A text input field containing 'POIC'.
- Local Information:** A section containing a 'Local IP Address' field with the value '192.168.50.9' and a 'Browse...' button.
- HOSC Information:** A section containing three fields:
  - HOSC Host Name:** A radio button (unselected) followed by an empty text input field.
  - HOSC IP Address:** A radio button (selected) followed by a text input field containing '192.168.50.9'.
  - HOSC Port:** A text input field containing '9209'.

At the bottom of the window, there is a 'Message Area' with a close button and a status bar showing 'Ready'.

**Figure 2 Main Window General Tab**

#### HOSC Login Name

The HOSC Login Name should contain a name for the login session. You will need this name when referencing the login session from other TReK Applications (e.g. HPEG, Command).

### Local IP Address


The Local IP Address is used to perform network communication when establishing the login session. If you are connecting to the HOSC, and have established a VPN Client login, you should enter the Office Mode IP Address assigned by the VPN Client. If you are connecting to a TReK training tool that is simulating the HOSC login, enter your computer's local IP address. You can use the Browse button to view and select a local IP Address.

### HOSC Information

HOSC information fields include the HOSC Host Name, HOSC IP Address, and HOSC Port. If you are connecting to the HOSC, enter the HOSC Host Name or IP Address and the HOSC Port. If you are connecting to a TReK training tool that is simulating the HOSC login, enter the IP Address and Port corresponding to the configuration of the training tool. For example, if you are running the training tool on the same computer as the HOSC Login application, then you would use your local IP address for the Local IP Address and the HOSC IP Address.

## 6.2 Advanced Settings


The Advanced Settings dialog provides access to a timeout value used in communication with the Huntsville Operations Support Center. It is unlikely there would ever be a need to modify this setting. The setting can only be modified when the Login session is inactive. The Advanced Settings dialog is shown in Figure 3.



**Figure 3 Advanced Settings Dialog**

## 6.3 Application Messages


Various types of application messages are generated including information, progress, warning, error, and debug messages. Information, warning, and error messages will be displayed in the main window message area. All application messages are sent to the Messages dialog shown in Figure 4. The Messages dialog can be configured to display specific types of messages. By default, the Messages dialog will display information, progress, warning, and error messages. Columns in the Messages dialog can be sorted by clicking on the column header. The Messages dialog is available from the Options menu.



**Figure 4 Messages Dialog**

### Configure


The Configure button provides access to the Configure Messages dialog shown in Figure 5. This dialog is used to filter the types of messages (category) displayed in the Messages dialog.



**Figure 5 Configure Messages Dialog**

### Clear

The Clear button provides access to the Clear Messages dialog shown in Figure 6. This dialog provides two ways to clear messages in the Messages dialog. You can clear all the messages or clear selected messages. Once you clear messages, the messages are permanently deleted.



**Figure 6 Clear Messages Dialog**

### Export

The Export button provides the capability to save all the application messages to a file. When you push the Export button you will be prompted for a directory and filename. Export will save all messages, not just the messages currently displayed in the Messages dialog (i.e. the 'Configure' filter is not applied). The name you provide for the file will be modified with a time tag appended to the filename. The time tag indicates the time the file was closed. For example:

Filename Input:        messages.txt  
Filename Output:      messages\_2017-05-07\_13~03~28.txt

## **6.4 Application Settings**

The HOSC Login application saves some settings as application settings each time you exit the application. The next time you run the application, the application will initialize with the previous application settings. The following application settings are saved:

- Application Window Size
- HOSC Login Name
- HOSC Host Name or HOSC IP Address Selection
- HOSC Host Name Entry
- HOSC IP Address Entry
- HOSC Port Entry
- Configure Messages Checkbox Selections
- Advanced Settings

## **7 FAQ and Troubleshooting**

This section addresses Frequently Asked Questions and provides tips for troubleshooting common gotchas.

No FAQs Yet.